

FIGURE 1




FIGURE 2




FIGURE 3









FIGURE 4






FIGURE 6a

09902065-100901





FIGURE 6b




FIGURE 7






FIGURE 8




FIGURE 9

0902056-100901




FIGURE 10a




FIGURE 10b




FIGURE 10c




FIGURE 10d




FIGURE 11




FIGURE 12




FIGURE 13




FIGURE 14




FIGURE 15







FIGURE 16

DISPLAY ACCESS TIMING DIAGRAM




FIGURE 17

09902066-100901




FIGURE 18a



# INPUTS FROM COPIER




FIGURE 18b

09902065-100901





FIGURE 18c



FIFO MEMORY ARRAY TIMING DIAGRAM

FIGURE 18d

100901 99020650




FIGURE 19a

COPIER MULTIPLEXED KEYBOARD WITH  
REMOTE KEYSTROKE MONITORING AND  
REMOTE KEYSTROKE GENERATOR CIRCUITRY

09902066-100901





FIGURE 19b

← COPIER CONTROL PANEL


→ SMART DATA TAP



09902065-100901



FD600T-9902060






FIGURE 19e




FIGURE 19f

MULTIPLEXED KEYBOARD TIMING DIAGRAM

DISPLAY TRADENAME AND HIGHLEVEL  
PICTURE OF OVERALL MONITORING  
STATUS. DISPLAY FAULT COPIERS  
BY CLASS: KEY OPERATOR, TECHNICIAN  
SERVICE AND OFF-LINE.

MAIN  
MENU

ESC: MENU MODE TOGGLE

USER  
MENU

GATEWAY TO INFORMATION  
OF ALL COPIERS

COPIERS

DISPLAY LIST OF ALL COPIERS  
AND PHYSICAL LOCATIONS

GATEWAY TO COPIER  
SERVICE RECORDS

SERVICE

DISPLAY LIST OF ALL COPIERS  
AND SERVICE RELATED FORMS FOR  
SELECTED COPIER.


SEE FIGURE 20b

SEE FIGURE 20c

FIGURE 20a

FUNCTION KEYS AVAILABLE AT EACH LEVEL

F1: ON-LINE HELP MESSAGES  
ESC: BACKUP ONE MENU LEVEL




SEE FIGURE 20d

SEE FIGURE 20e

FIGURE 20b

FROM FIGURE 20a



DISPLAY HISTORICAL INFO  
OF SPECIFIED COPIER

- \*GROUPED BY FAILURE CLASSIFICATIONS

DISPLAY FACTUAL PROFILE  
OF SPECIFIED COPIER;

- \*MODEL/SERIAL NUMBER
- \*PHYSICAL LOCATION
- \*FACILITIES INFORMATION
- \*INSTALLATION DATE
- \*LAST SERVICE DATE

REAL TIME COPIER DISPLAY  
PANEL MONITORING MODE

- \*ALL STATUS INDICATORS
- \*ALL SETUP INDICATORS
- \*COPY COUNTS
- \*ERROR CODES
- \*POP-UP ERROR CODE HELP SCREENS

FIGURE 20c




FIGURE 20d



FROM FIGURE 20a




FIGURE 20e




FIGURE 20f



MONITOR

ID: 001  
 TYPES: X-1025  
 LOCATION: LAB  
 STATUS: OFFLINE

CLEAR PAPER PATH      ADD DRY INK      INSERT PAPER TRAY      PLEASE WAIT      CHECK PAPER SIZE

ADD PAPER      REPLACE SUMP      JOB INTERRUPT      READY TO COPY      CHECK SORTER

NUMBER TO COPY: 00      ORIGINAL SIZE:      TRAY #0  
 CONTRAST: NORMAL      COPY PAPER SIZE: 000  
 PERCENT:

1-HELP      ESC-EXIT MONITOR

SCREEN 6:      MONITOR 1025 COPIER

FIGURE 21

# MONITOR

# ERROR CODES

 $\dot{u}$ 

## TYPES:

**LOCATION:**

**STATUS:**

CLEAR

PAPER

## PATH

ADD

PAPER

NUMBER

# CONTRA

ay #0

A1	-	CLEAR MISFED ORIGINALS	
A2	-	CLEAR MISFED ORIGINALS	
A6	-	RECOPY LAST ORIGINAL	
A7	-	RECOPY LAST 2 ORIGINAL	
A9	-	DOCUMENT HANDLER FAILURE	
C1	-	REMOVE TRAY 1 - CLEAR MISFED	PAPER IN TRAY
C2	-	REMOVE TRAY 2 - CLEAR MISFED	PAPER IN TRAY
C3	-	REMOVE TRAY 3 - CLEAR MISFED	PAPER IN TRAY
C9	-	REMOVE MISFED COPY PAPER AND REFEED	
E1	-	CLEAR PAPER PATH FROM CENTER	
E3	-	CLEAR PAPER PATH FROM EXIT	
E5	-	CLOSE FRONT COVER	
F1	-	CHECK SORTER PATH	
F5	-	RETURN SORTER TO CLOSED POSITION	
F8	-	SORTER POWER FAILURE	
F9	-	SORTER BIN FAILURE	
J7	-	REPLACE WASTE SUMP	
D6	-	INSERT KEY COUNTER	
Ux	-	CALL FOR SERVICE (U1 -- U8)	

1-Help ESC-EXIT MONITOR

SCREEN 7:

# ERROR CODES FOR 1025

FIGURE 22